


E-7 Gearshift Drum



E-7 Gearshift Drum



Ref. No.	Part No.	Description	Reqd. No. CR250M	Serial No.	Area Code
1	24211-357-020	FORK, R. GEARSHIFT	1		
2	24221-357-020	FORK, L. GEARSHIFT	1		
3	24231-357-020	FORK, CENTER GEARSHIFT	1		
4	24261-357-000	PIN, GEARSHIFT FORK GUIDE	1	1010668	
	24261-357-010	PIN, GEARSHIFT FORK GUIDE	1	1010669	
5	24262-357-000	COLLAR, GUIDE PIN 24261-357-010	1	1010668	
6	24263-357-000	CLIP, GEARSHIFT FORK GUIDE PIN	1		
7	24265-357-010	SHAFT, GEARSHIFT FORK GUIDE	1		
8	24301-357-020	DRUM COMP., GEARSHIFT 24301-357-030	1	1010374	
	24301-357-030	DRUM COMP., GEARSHIFT	1	1010375	
9	24307-357-300	PLATE, DRUM PIN STOPPER	1		
10	24420-357-010	ARM COMP., NEUTRAL STOPPER	1		
11	24425-357-000	COLLAR, NEUTRAL STOPPER	1		
12	24430-357-010	ARM COMP., DRUM STOPPER	1		
13	24435-357-020	SPRING, NEUTRAL STOPPER ARM	1		
14	24436-357-040	SPRING, DRUM STOPPER ARM	1		
15	24438-216-000	COLLAR, SHIFT DRUM STOPPER	1		
16	24600-357-000	SPINDLE ASSY., GEARSHIFT	1		
17	24641-292-000	SPRING, GEARSHIFT ARM	1		
18	24651-357-010	SPRING, GEARSHIFT RETURN	1		
19	24701-357-000	PEDAL, GEARCHANGE	1		
20	90617-302-000	WASHER, SHIFT DRUM STOPPER	2		
21	92000-06018	BOLT, HEX., 6X18	1		
22	92000-06020	BOLT, HEX., 6X20	1		
23	92000-06028	BOLT, HEX., 6X28	1		
24	93600-06014	SCREW, FLAT, 6X14	1		
25	96221-40100	ROLLER, 4X10	4		