
The starter motor turns when the transmission is in neutral, but does not turn with the transmission in any position except neutral, with the side stand up and the clutch lever pulled in.



## Starter motor turns engine slowly

- · Low battery voltage
- · Poorly connected battery terminal cable
- Poorly connected starter motor cable
  Faulty starter motor
- Poorly connected battery ground cable

## Starter motor turns, but engine does not turn

- Starter motor is running backwards
  Case assembled improperly
  - Terminals connected improperly
- Faulty starter clutch
- Damaged or faulty starter drive gear

## Starter relay switch "Clicks," but engine does not turn over

Crankshaft does not turn due to engine problems