


## TURN SIGNAL

### BULB REPLACEMENT

#### Front

Remove the rearview mirror boot.

Remove the bolts and mirror.




Turn the bulb socket counterclockwise and remove it.



While pushing in, turn the bulb counterclockwise to remove it and replace with a new one.

Install the front turn signal in the reverse order of removal.



#### Rear

Remove the screw and turn signal lens.

