


## FRAME/BODY PANELS/EXHAUST SYSTEM

Install the air duct joints into the air cleaner housing.

Install the rubber and relays onto the left air duct joint.



Connect the front sub-harness connectors, combination meter multi-connector.

Install the upper cowl, aligning the bosses with the grommets on the meter stay.

