

## INSTALLATION

Install the oil pump control cable and throttle cable into the carburettor

Install carburettor into insulator and tighten band

Connect oil path tube to carburettor  
Connect choke cable to carburettor

Check for foreign particles and abnormal conditions and install chamber to insulator

\* When installing intake chamber, ensure that it is position against the stopper and tighten band

Inspect throttle grip play ( 2-15)  
Adjust oil pump control cable ( 2-14)  
Install air cleaner case ( 4-3)  
Install fuel tank ( 4-2)  
Bleed oil pump ( 3-4)  
Adjust air screw ( 4-16)  
Adjust idling ( 2-12)  
Synchronize ( 4-16)  
Install lower fairing ( 15-5)

