

Install pad spring

Apply silicon grease to pivot collar
O.D and boot I.D
Install pivot collar and boot into
caliper

Installation

Install brake pads
Apply silicon grease to caliper pinch
bolt and caliper bracket pin

Install caliper to bracket, turn downwards
and set over disc

* take care not to damage brake pads

Tighten caliper pinchbolt
Torque: 2.0-2.5 kg-m

Assemble hanger pin retainer and tighten
bolt
Torque: 0.8-1.3 kg-m

Install 2 sealing washers and brake
hose bolts and tighten hose bolts
Torque: 2.5-3.5 kg-m

Fill with brake fluid and bleed air
(14.3)

BRAKE PEDAL

Removal

Remove side cover (15.1)
Remove R. step stay

Remove stop light switch spring from
pedal
Remove brake hose crammer

SILICON
GREASE PIVOT COLLAR

