

GENERAL INFORMATION

TOOLS

SPECIAL

DESCRIPTION	TOOL NUMBER	REFER TO SECTION	
Bearing puller catch	07931 - MK20100	10	
Knock pin puller set	07936 - MA70000	}	
- Remover weight	07741 - 0010201		6
- Slider shaft	07936 - MA70100		6
Tensioner holder	07973 - MG30003	6	
Valve guide reamer	07984 - 5510000	6	
Bearing remover set	07936 - 3710001	}	
- Spindle	07936 - 3710600		10, 13
- Remover handle	07936 - 3710100		
- Remover weight	07741 - 0010201		
Bearing remover, 15 mm	07936 - KC10500	10	
Remover handle	07936 - MK50100	10	
Remover weight	07741 - 0010201	10	
Crankcase assembly tool	07931 - KF00000	}	
- Collar	07931 - KF00100		10
- Thread adapter	07931 - KF00200		
- Shaft puller	07931 - ME40000		
Oil seal driver attachment	07GAD - SD40101	10	
Ball race remover	07953 - MJ1000	12	
Slider weight	07947 - KA50100	12	
Fork seal driver attachment	07947 - KA40200	12	
Steering stem nut wrench	07916 - KA50100	12	
Compression gauge attachment	07908 - KK60000	3	
Steering stem driver	07946 - 4300101	12	
Bearing driver	07946 - MJ00100	13	
Damping valve wrench	07920 - KA30001	13	
Bearing driver base	07HMF - KS60100	13	
Spherical bearing driver	07946 - KA30200	13	
Needle bearing remover	07931 - MA70000	13	
Snap ring pliers	07914 - 3230001	14	
Slider guide, 14 mm	07974 - KA40000	13	
Piston ring sleeve	07974 - KA30201	13	
Slider guide attachment	07974 - KA30100	13	