

TOOLS**Special**

| | |
|-----------------------------|---------------|
| Steering stem nut wrench | 07916—KA50100 |
| Steering stem driver | 07946—4300101 |
| Fork seal driver | 07947—KA50100 |
| Fork seal driver attachment | 07947—KA40200 |
| Ball race remover | 07953—MJ10000 |

Common

| | |
|------------------------|---------------|
| Wrench, 30 x 32 mm | 07716—0020400 |
| Remover head, 15 mm | 07746—0050400 |
| Bearing remover shaft | 07746—0050100 |
| Attachment, 42 x 47 mm | 07746—0010300 |
| Pilot, 15 mm | 07746—0040300 |
| Driver | 07749—0010000 |
| Attachment, 32 x 35 mm | 07746—0010100 |
| Extension bar | 07716—0020500 |

TROUBLESHOOTING**Hard Steering**

- Steering stem nut too tight
- Faulty steering stem bearings
- Insufficient air in front tire

Steers to One Side or Does Not Track Straight

- Bent fork
- Bent front axle, wheel misaligned
- Wheel installed incorrectly

Front Wheel Wobbling

- Distorted rim
- Worn front wheel bearings
- Loose or broken spokes
- Faulty tire
- Axle not tightened properly

Soft Suspension

- Weak fork springs
- Insufficient fluid in fork legs
- Incorrect fork air pressure

Hard Suspension

- Incorrect fluid weight in fork legs
- Incorrect fork air pressure
- Fork tube bent

Front Suspension Noise

- Slider binding
- Insufficient fluid in fork legs
- Loose fork fasteners