

SERVICE INFORMATION	15-1	EXHAUST PIPE	15-3
REAR FENDER	15-2		

## SERVICE INFORMATION

### GENERAL

- This section describes removal/installation of the rear fender and exhaust pipe.
- Temper color stainless steel is used for the exhaust pipe. If the engine is started with the exhaust pipe stained with the grease; it causes patches in the color.  
To remove the patch, grind the pipe with the fine compound, clean it with a kitchen detergent aimed for the stainless steel, flush it, and wipe it with a dry cloth.

#### **▲ WARNING**

- *Do not service the exhaust system while it is hot.*

### TORQUE VALUES

Exhaust pipe joint nut	27 N·m (2.7 kg-m, 20 ft-lb)
Muffler mounting bolt	70 N·m (7.0 kg-m, 51 ft-lb)
Exhaust pipe protector	10 N·m (1.0 kg-m, 7 ft-lb)
Exhaust pipe clamp bolt	27 N·m (2.7 kg-m, 20 ft-lb)