

TROUBLESHOOTING

ENGINE DOES NOT START OR IS HARD TO START	19-1	POOR PERFORMANCE AT HIGH SPEED	19-4
ENGINE LACKS POWER	19-2	POOR HANDLING	19-4
POOR PERFORMANCE AT LOW AND IDLE SPEEDS	19-3		

ENGINE DOES NOT START OR IS HARD TO START

Probable Cause

