

[illegible]

	HI	(H ₂)	LO
≡D	○	○	
(N)	○	○	○
≡D		○	○
CONF. COLOR	Bu		W

**INTERRUPTOR DE LA SEÑAL DE GIRO
DIRECCIONALES**

	L1	W1	R1	L2	W2	R2
↓	○	○		○		
(N)						
↑		○	○		○	○
CORO COLOR	0	Gr	lb	QW	Gr	ΔW

INTERRUTTORE CLACSON INTERUPTOR DE LA BOCINA KLAKONSCHAKELAAR	HO	B
FREE		
PUSH	○	○
CONO COLOR	Lg	Bli

Br MABRONE
 Lo ARANCIONE
 Lb AZZURRO
 G VERDECHIARO
 P ROSA
 Gr GRIGIO
 Br MARRON
 Lo NARANJA
 Lb CELESTE
 G VERDE CLARO
 P ROSADO
 Gr GRIS
 Br BRUIN
 Lo ORANJE
 Lb LICHTBLAUW
 G LIGHTGREEN
 P ROZE
 Gr GRUIS
 Br NERO
 Lb GIALLO
 G VERDE
 P ROSSO
 W BIANCO
 Br NEGRO
 Lb AZUL
 G VERDE
 P ROJO
 W BLANCO
 Br ZWART
 Lb GEEL
 G BLAUW
 P GROEN
 R ROOD
 W WIT

0030Z-MBN-6800