	FREQUENCY	WHICHEVER → COMES FIRST ↓		ODOMETER READING [NOTE (1)]							
			× 1,000 km	1	6	12	18	24	30	36	REFER TO PAGE
			× 1,000 mi	0.6	4	8	12	16	20	24	
	ITEM	NOTE	MONTH		6	12	18	24	30	36	
	DRIVE CHAIN			EVERY 1,000 km (600 mi) I, L							108–112
	DRIVE CHAIN SLIDER					I		I		I	113
	BRAKE FLUID	NOTE (3)			I	I	R	I	I	R	31–33
	BRAKE PAD WEAR				I	I	I	I	I	I	122
	BRAKE SYSTEM			I		I		I		I	31–33, 124
*	BRAKE LIGHT SWITCH					I		I		I	130
*	HEADLIGHT AIM					I		I		I	–
	CLUTCH SYSTEM					I		I		I	34
	CLUTCH FLUID	NOTE (3)			I	I	R	I	I	R	34
	SIDE STAND					I		I		I	115
*	SUSPENSION					I		I		I	114
*	NUTS, BOLTS, FASTENERS			I		I		I		I	–
**	WHEELS/TYRES					I		I		I	–
**	STEERING HEAD BEARINGS			I		I		I		I	–