

Parking brake lever (P114)

Front suspension spring preload/rebound damping adjusters (P129) (P130)

Engine oil fill cap (P104)

Fuel fill cap (P69)

Tool kit/Tool box (P72) (P101)

Front seat (P98)

Fuse boxes (P154)

Battery (P95)

Rear suspension spring preload adjuster (P132)

Rear suspension rebound damping adjuster (P133)

Engine oil drain bolts (P106)

Drive chain (P117)

Side stand (P116)

Engine oil dipstick (P104)

Crankcase breathers (P126)