

Storage Compartment

The storage compartment (Fig. 2-23) is behind the seat. To open the compartment, unhook the rubber straps (3) and lift the hinged section of the rear rack (4). The Owner's Manual (5), tool kit (6), and air pressure gauge (7) should be stored in the storage compartment.

To secure the Owner's Manual in the compartment, use the manual holder (8) and hook (9).

Be careful not to flood this area when washing your FOURTRAX.




Fig. 2-23

- (1) Seat
- (2) Storage compartment
- (3) Rubber straps (For the rear rack section and the storage compartment)
- (4) Rear rack section
- (5) Owner's manual
- (6) Tool kit
- (7) Air pressure gauge
- (8) Manual holder
- (9) Manual holder hook