


# Controls & Features

---

## Parking Brake

### LEFT HANDLEBAR



(1) lock lever

(2) rear brake lever/parking brake lever      (A) to lock

The lock lever (1) on the rear brake lever/parking brake lever (2) allows it to be used as a parking brake. To operate, first squeeze the rear brake lever/parking brake lever using your left hand and then lock it with the lock lever using your right hand. See *Parking* page 124.

The brakelights are activated by applying the parking brake. When using the parking brake, be sure to turn the ignition switch OFF ( ○ ) to avoid discharging the battery.