

Braking

For normal braking, apply the front and rear brakes together. Gradually increase braking pressure as you feel the brakes slowing your speed.

Applying the brakes too hard may cause the wheels to lock, and you can start sliding out. If this happens, release the brakes, steer straight ahead until you regain control, then reapply the brakes more gently.

When possible, reduce your speed or complete braking before entering a turn. A quick closing of the throttle or any braking during a turn may cause one or both wheels to slip.

When you brake to a stop, pull the clutch lever in before stopping completely to prevent stalling the

engine. For support, put your left foot on the ground first, then your right foot when you're through braking.