

Installation

1. Position the wheel between the fork arms and insert the front axle through the right arm of the fork and the wheel hub.
 - Avoid scratching the brake pads and position the brake disc carefully between the pads.
2. Apply pressure to the axle.

Torque: 70 N•m (7.0 kgf•m).

3. Lower the front wheel to the ground.
4. Press the brake lever several times. Then press on the fork several times.
5. Tighten the axle pinch bolt.

Torque: 21 N•m (2.1 kgf•m).

6. Lift the front wheel off the ground again and check that it turns without difficulty once the brake is released.
7. Lower the front wheel to the ground again.

If a torque wrench was not used for installation, see your dealer as soon as possible to verify proper assembly.

Improper assembly may lead to the loss of braking capability.