

# Tires

---

Always check air pressure when your tires are “cold.” If you check air pressure when your tires are “warm” — even if your Honda SXS has only been driven for a few miles — the readings will be higher. If you let air out of warm tires to match the recommended cold tire pressures, the tires will be underinflated. Be sure to check tire pressure at the driving site, since changes in altitude can affect air pressure.

The recommended “cold” tire pressures are:

	Up to 661 lb (300 kg) load	Up to maximum weight capacity
FRONT	10 psi (70 kPa)	10 psi (70 kPa)
REAR	12 psi (80 kPa)	18 psi (120 kPa)