

## Periodic Checks

You should also perform other periodic maintenance checks at least once a month regardless of how often you ride, or more often if you ride frequently.

Also, check the odometer reading against the Maintenance Schedule and perform all maintenance that is due. ➔ [P. 37](#)

Tires and wheels	Check the air pressure (➔ <a href="#">P. 50</a> ), examine tread for wear and damage (➔ <a href="#">P. 51</a> ), and check the wheels for damage.
Fluid levels	Check the engine oil level (➔ <a href="#">P. 60</a> ), engine coolant level (➔ <a href="#">P. 67</a> ), clutch fluid level (➔ <a href="#">P. 73</a> ), and brake fluid level (➔ <a href="#">P. 70</a> ).
Lights	Check that the headlight, brake light, taillight, turn signals and license plate light are working properly.
Controls	Check the freeplay of the clutch lever (➔ <a href="#">P. 79</a> ), throttle grip (➔ <a href="#">P. 78</a> ), front brake lever (➔ <a href="#">P. 79</a> ) and rear brake pedal.
Drive chain	Check the slack (➔ <a href="#">P. 75</a> ), adjust the slack (➔ <a href="#">P. 76</a> ), and lubricate (➔ <a href="#">P. 48</a> ) as needed.
Fuses	Check that you have a full supply of spare fuses.
Nuts & bolts	Check the major nuts and bolts, and tighten as needed.