

Keeping your CRF well maintained is absolutely essential to your safety. It's also a good way to protect your investment, get maximum performance, avoid breakdowns, and have more fun.

To help keep your CRF in good shape, this section includes a Maintenance Schedule for required servicing and step-by-step instructions for specific maintenance tasks. You'll also find important safety precautions, information on oils, and tips for keeping your Honda looking good.

An ICM (Ignition Control Module) system is used on this motorcycle; consequently, routine ignition timing adjustment is unnecessary. If you want to check the ignition timing, refer to the Honda Shop Manual.

An optional tool kit may be available. Check with your Honda dealer's parts department.

Before You Service Your Honda

The Importance of Maintenance 18

Maintenance Safety 19

 Important Safety Precautions..... 19

Maintenance Schedule 20

General Competition Maintenance 22

Before & After Competition Maintenance..... 26

 Between Motos & Practice Maintenance 26

 After Competition Maintenance 26

Service Preparations

Maintenance Component Locations..... 28

Seat Removal..... 29

Fuel Tank Removal 30

Subframe Removal 32

Service Procedures

Fluids & Filters

Fuel System 34

Engine Oil 36

Transmission Oil 39

Coolant 41

Air Cleaner 43

Crankcase Breather 45

Engine

Throttle 46

Engine Idle Speed 48

Clutch System 49

Hot Start Lever 54

Spark Plug 55

Valve Clearance..... 56

Piston/Piston Rings/Piston Pin..... 64

Chassis

Suspension..... 72

 Front Suspension Inspection..... 72

 Rear Suspension Inspection..... 73

 Fork Oil Change 74

Brakes..... 77

Wheels 81

Tyres & Tubes 82

Drive Chain 84

Exhaust Pipe/Muffler 87

Steering Damper..... 91

Additional Maintenance Procedures 93

Appearance Care 95