

Riding Tips

Riding Tips

- Check the side stand is retracted before riding – selecting a gear.
- Use the gears within the speed ranges given in the table.
- To save fuel and prolong the life of the motorcycle, avoid rapid acceleration or deceleration.

Gear	Speed Range
1 st	0-40 km/h
2 nd	10-65 km/h
3 rd	20-90 km/h
4 th	30-120 km/h
5 th	40-145 km/h
6 th	60 km/h and above



Advice

If you notice any unusual sound or other problems, contact an authorized HONDA dealer as soon as possible.



Tip

- Accelerate as gently as possible.
- Always observe the speed limit.

Running In

Keep the engine in relatively lower rpm and avoid rapid acceleration and deceleration for the first 500km. This will prolong the life of the engine.