

High Altitude Riding

When operating this vehicle at high altitudes, the air-fuel mixture becomes overly rich. Above 6,000 feet (1,800 m) driveability and performance may be reduced and fuel consumption increased. The carburetor can be modified to compensate for this high altitude richness. However, the carburetor must be returned to standard factory specifications when lower altitude riding is desired. (See page 49.)

CAUTION:

- * *Sustained operation at altitudes below 5,000 feet (1,500 m) with high altitude carburetor modifications may cause engine overheating and damage.*
- * *Tire pressures can change significantly as you go up and down in a attitude; therefore, always check tire pressures just before you start riding.*

PARKING

1. Stop the vehicle, shift the transmission into neutral, turn the fuel valve and ignition switch OFF.
2. Pull the parking brake lever and lock it. (See page 14.)