




Suspension

To adjust to the standard position:



- (1) rebound damping adjuster
- (2) punch mark
- (3) reference mark

1. Turn the adjuster (1) clockwise until it will no longer turn (lightly seats). This is the full hard position.
2. Turn the adjuster counterclockwise 3 clicks until the punch mark (2) on the adjuster aligns with the reference mark (3).
3. Make sure that both fork legs are adjusted to the same position.

