



Suspension

Condition	Step 1	Step 2	Step 3
Bottoming	shorten the spring length (to increase pre-load)	turn the compression adjuster to a stiffer position (to increase damping force)	turn the rebound adjuster to a stiffer position (to increase damping force)
Soft	turn the compression adjuster to a stiffer position (to increase damping force)	shorten the spring length (to increase pre-load)	turn the rebound adjuster to a softer position (to decrease damping force)
Hard	increase the spring length (to decrease pre-load)	turn the compression adjuster to a softer position (to decrease damping force)	turn the rebound adjuster to a softer position (to decrease damping force)
Excessive Sinking	shorten the spring length (to increase pre-load)		



Make changes one step at a time. Test ride your motorcycle after each adjustment. If necessary, proceed to the next step.

