

GENERAL INFORMATION

Item	Q'ty	Thread Dia. (mm)	Torque N·m (kg-m, ft-lb)	Remarks	
Steering bearing adjusting nut	1	26	3 (0.3, 22)	Apply oil	
Steering stem nut	1	24	118 (11.8, 85)		
Front brake disc	6	6	15 (1.5, 11)		
Brake master cylinder bleeder screw	1	8	6 (0.6, 4)		
Rear axle nut	1	16	95 (9.5, 69)		
Rear spoke	1		4 (0.4, 3)		
Rear wheel rim lock	1		13 (1.3, 9)		
Final driven sprocket	6	10	46 (4.6, 33)		
Rear shock absorber upper mount	1	10	45 (4.5, 33)		
Rear shock absorber lower mount	1	10	30 (3.0, 22)		
Swingarm pivot nut	1	14	90 (9.0, 65)		
Shock arm-to-swingarm bolt	1	12	45 (4.5, 33)		
Shock arm-to-shock link bolt	1	10	45 (4.5, 33)		
Shock link-to-frame bolt	1	10	70 (7.0, 51)		
Rear shock spring adjuster lock nut	1	50	90 (9.0, 65)		
Rear shock hose joint bolt	1	10	30 (3.0, 22)		
Rear shock hose lock nut	1	12	30 (3.0, 22)		
Rear shock piston rod end nut	1	12	38 (3.8, 27)		Apply LOCTITE® 242 or equivalent
Brake pedal pivot bolt	1	12	40 (4.0, 29)		
Brake caliper bolt	2	8	27 (2.7, 20)		
Brake caliper bleeder screw	1	8	6 (0.6, 4)		
Brake pad pin	2	10	18 (1.8, 13)		
Fuel valve	2	6	10 (1.0, 7)		
Gearshift pedal	1	6	10 (1.0, 7)		
Kick starter arm	1	8	27 (2.7, 20)		
Brake hose joint bolt	2	10	35 (3.5, 25)		

Torque specifications listed above are for the most important tightening points. If a specification is not listed, follow the standard torque values below.

STANDARD TORQUE VALUES

Item	N·m (kg-m, ft-lb)	Item	N·m (kg-m, ft-lb)
5 mm bolt and nut	6 (0.6, 4)	5 mm screw	4 (0.4, 3)
6 mm bolt and nut	10 (0.1, 7)	6 mm screw and 6 mm bolt with small (8 mm) head	9 (0.9, 7)
8 mm bolt and nut	22 (2.2, 16)	6 mm flange bolt and nut	12 (1.2, 9)
10 mm bolt and nut	35 (3.5, 25)	8 mm flange bolt and nut	27 (2.7, 20)
12 mm bolt and nut	55 (5.5, 40)	10 mm flange bolt and nut	40 (4.0, 29)